


## U2O Includes Tip Adapters Shown Below (Laptop Tip)






NO	Manufacturer	Series	Model Number	Tip
1	ASUS		A1000 series, AtrBook L7336, B1000series, F7000, Grandio F7400, F7400,L1000Bseries,L2000Bseries, L2000Eseries, L3000Cseries, L3000S series, L7000, L7000C, L7200, L7233, L7300, L8400, M1000 Series, m2000series, m2series, mp8xxxseries, s1000series, t4700CS,T7200, T9000 series	
	HP	Armada	110,E300, E500 series, E700 series, M300 series, M700series, v300 series,600 series,800 series, m-series	
		EVQ	N40, N110, N150, N160, N180, N200, N200C, N400C, N410C, N600C, N610C, N800C, N800V Series, N800W, N1000C, N1000V, N1015V, N1020V, N1050V	
		Prosignia	150, 160, 170, 190	
		Business notebook	nc4000 series, nc4010 series, nc6000 series, nc8000 series, nw8000 series, nx7000 series, nx5000 series,nx7000 series, nx7010 series, nv7100 series, nx9000 series,nx9040v	
		Presario	900, 2800, 2800t, 2805US	
Trigem	Dreambook	A Series, F Series, T Series, U Series, X Series		
2	Acer	Trave-lmate	200, 201, 202, 203, 204, 205, 210, 212, 213, 220, 222, 260, 261, 310-314, 330, 332, 333, 340-347, 350-354, 361-364, 501-517, 520, 521, 524, 525, 527-529, 534, 600, 602-604, 610-614, 620-623, 630-633, 710, 720-723, 730, 732, 734-744	
3	Acer	AcerNote	367, 390 Series	
		T1 Extensa	390, 390c, 391, 392, 393, 394, 395, 512, 513, 514, 515, 516, 617, 610, 610CD,610CDT, 616series, 620series, 690series, 900series	
	AMS Tech	Rodeo	1000 series,1010series,7000,7030,7620,7630,7640XL	
		Travel-Pro	180, 1900	
	HP	EVQ	N105,N115,N160,N180	
		Presario	700 series, 1000 series, 1200 series, 1245 series, 12xl series,14xl series, 1600 series,1700 series, 17xl series, 1700t, 1700xl573, 1710SB, 1800 series, 18xl series, 1800 XL, 2100 series, 2500 series, 2700 series, 2700t, 800, 800xl	
		Contura	386/486 series, 400c, 400cx, 410, 410cx, 420c, 420cx, 430c, 430cx	
		Pavilion	ZT1131, ZT1132, ZT1135, ZT1141, ZT1142, ZT1145, ZT1151, ZT1152, ZT1155, ZT1161, ZT1162, Zt1171, ZT1172,ZT1175, ZT1180, ZT1181, ZT1182, Zt1185, ZT1190, ZT1192, 5200 series, 5400 series, pavilion ZE ZT, zu series, XH455,XH485, XH535, XH545, Xh555, XH575, XH675, XU155, XZ185, XZ275, ZE1110, ZT1114, ZT1120, ZT1121, ZT1125, ZT1130, N3000 series, n3200 series,n3300 series, n5000 series, n5300 series, n5400 series, n5500 series, dv1000 series, dv4900 series, Zf3000 series, ze4000 series, ze5000 series	
Omni-book		2000, 2100, 2103, 2105, 2106, 2120, 2121, 2122, 2123, 2124, 2125, 2126, 2127, 3000, 3000CTX, 3100, 3101, 3250 series, 4000, 4000c, 4000ct, 4000e, 4000m,4100, 4150, 4150B, 6000 Series, 6100 series, 7000 series, 6050, 6020, Vt6200,Xt1000, XT15 2000, 7100 Series, +D97103, 7150 series, xE series, xe2 series, xe3 series, 900 series		






3	HP	Omni-book	N3100, N3110, N3150, N3200, N3250, N3270, N3290, N3295, N3300, N3390, N3400, N3402, N3401, N3438, N3478, N3490, N5000, N5100, N5125, N1340, N5150, N5170, N5190, N9195, N5200, N5210, N5240, N5250, N5270, N5290, N5295, N5300, N5310, N5311, N5340, N5421, N5422, N5425, N5430, N5435, N5440, N5441, N5442, N5444, N5445, N5450, N5452, N5454, N5455, N5461, N5462, N5470, N5472, N5474, N5475, N5481, N5482, N5484, N5490, N5491, N5495, N5511, N5584, N6195, N6395, N6396, N6397, N6398, N6399, N6400, N6401, N6403, N6404, N6490.
	DELL		433M, 43MC, 433MCX, 450MC, 450MCX, 475C, 475D, 475MC, LX, LXX, 4100/T
		Inspiron	3000, 3200, 3500, 7000 series
	IBM		1200, 1210, 1230, 1250, 1260, 1300, 1330, 1400, 1412, 1418, 1420, 1434, 1435, 1436, 1442, 1470, 1472, 1476, 1480, 1500, 1512, 1540, 1541, 1552, 1560, 1700, 1720, 1721
		Think-pad	235, 240, 290, 310, 340, 345, 365, 380, 385, 390, 535, 560, 570, 600, 701, 770, 2621-xxx, 1161-xxx, 1171-xxx, 600x series, 2645, 2611A, T, X&R Series, transnote
	NEC		300, 320, 610, 620, 650, 660, 3400, 3600, 7000, 7010, 7020, 7030, 7140, 7200, m200 tablet
	Sager		6200 Series, 7200, 8549 D20, 86, 862, 87, 8700, 98, Nb8600, NB8700, NP8100, NP8300 series, Np8500 series, NP8600 series, NP8700, Pentium 86
			5100C, NP501, NP3360V
Sharp	PC	3010, 3020, 3050, 3060, 3150	
Toshiba	Satellite	A85,1000,1005,1600,1605,1625,1700,3000	
4	NEC	Versa	LX series, SX series
	SONY	Libretto	20ct,30ct,50ct,60ct,70ct
		protégé	300, 320,610, 620, 650, 660, 3400, 3600, 7000, 7010, 7020, 7030, 7140, 7200, m200 tablet
	Toshiba	Satellite	T200 Thru 4100, 200, 220, 225, 305, 315, 320, 325, 330, 335, 440, 460, 470, 480,490, 1555, 1800, 2000, 2100, 2140, 2180, 2210, 2280, 2500, 2590, 2600, 2615, 2655, 2675, 2700, 2715, 2800, 2805, 4000, 4010, 4020, 4030, 4060, 4080, 4100,4200, 4280, 4300, 4600, 1800-s203, 1800-s253, 2250xcds, 2250cdt
		Satelite pro	400, 405, 410, 415, 420, 425, 430, 435, 440, 445, 460, 465, 470, 480, 490, 490x, cdx, cds
		Tecra	500, 505, 510 including, cdt m1, m2, s1730x, 520, 530, 550, 700, 710, 720, 730,730x, 740, 750, 780, 8000, 8100, 8200, 9000
		4090xdvd, 2546CDS	
5	SONY	Vaio	Pcg-xg, 808, 812, 818, 838, PCG-r600, qr series, PCG-430 thru 490, PCG-431, PCG-450, PCG-461, PCG-480, PCG-481, PCG-490, PCG-491, PCG-700, PCG-705c,PCG-707c, PCG-747, PCG-717c, PCG-719c, PCG-731, PCG-737, PCG-745, PCG-747, PCG-705 thru 748c, xg series,580, 800, PCG-900, vadio pcg-955a, pcg-z505, PCG-z600, PCG-r600, QR Series, PCG-735
			GR, SR, SRX, VX series, PCG-505, PCG-505ex, PCG-505f, picturebook, PCG-c1x, 505, PCG-505fx, PCG-505g, PCG-505gx, PCG-505ls, PCG-505tR, PCG-505ts, PCG-505tx, PCG-505x, picturebook PCG-c1x
	DELL		LX450, XP4100, XP4100C, XP4100CX, XP4100T, XP450C, XP475C, XP475D

5	Fujitsu	Series	B, C, E, FMV, CX, L, I, S	
		Life-Book	270DX, 280DX, 400, 420, 420DX, 435DX, 470, 520, 520D, 520T, 530, 530T, 531T, 531TX, 535T, 535TX, 555TX, 5651TX, 585TX, 635, 635T, 635TX, 655, 655TX, 656TX, 675TX, 690TX, 735CDT, 735TX, 755TX, 756DX, 765TX, 770TX, 785TX, 790TX, 985TX, 990TX, 990TX2	
			Lifestyle, Milan, MontegoFujitsu lifeStyle, pen centra 200, Stylistic 3400, stylistic 2300, stylistic 1200, point 1600, point 510, stylus 3400 tablet	
6	DELL	Latitude	D400, D410, D500, D505, D600, D610, D800, D810, X300	
		Precision	M20/m60/m70 workstation	
7	IBM		1109 / 1100 / 1101 / 1102 / 1103 / 1104 / 1105 / 1106	
8	Acer	T1 Extensa	501, 502, 503, 600series, 700series, 712series	
		Precision	M20/m60/m70 workstation	
	AMS Tech		MP-975A	
		Rodeo	3500 Series	
		TravelPro	100 Series, 12CT, 1950 Series, 1961 Series, 1965, 1970CT, 2000, 6000 Series	
	DELL	Latitude	433 Series, 450 Series, 475 Series, LX, LX 4100 Series	
	Gateway	Solo	1100, 2100, 2150, 2200, 2300 Series, 2500 Series, 5100 Series, 9100 Series, 9300 Series	
	HP	Armada	100, 4100, 4200 series 1100, 1120, 1125, 1130, 4100, 4110, 4110D, 4110T, 4120, 4120T, 4124D, 4125D, 4130, 4130T, 4131, 4131T, 4150T, 4160, 4160T, 4210T, 4220T	
		Contura	3/20, 3/25, 3/25c, 4/20, 4/25, 4/25c, 4/25cx	
	IBM	Thinkpad	1410, 1411, 1441, 1450, 1451, 1472 series	
		Thinkpad	730t, 350 series, 500, 510 series	
	NEC		Ready 220t, ready 330t, ready 340t, ready 360t	
Toshiba	Satellite	T1850, T1900, T1910, T1950, T1960, T2400, T3400, T3600, T4500, T4600, T4700, T4700C, T4700CS, T4700CT, T4700, T4800, T4800CT, T4850CT, T4900, T4900CT, T4950CT		
9	SamSung		X Series, R Series, G Series, M Series, P Series, X Series	

## U2O Includes Tip Adapters Shown Below (Digital Mobile Tip)

NO	Manufacturer	Series	Model Number	Tip
1	Belkin	Wi Fi Phone	Skype	
	Motorola		A1200/A630/A668/A70/A732/A780/A840/A845/A910/ACTV W450/C305 C330/C331g/c332g/T193/C331t/C333c/C343/C350/C353t/C362/C363 E1070/E310/E610/E615/E680/E680i/E685/E770v/EM325/EM330/ Exterme VA76r/H270/H3/H350/H375/H390/H500/H550/H605/H670 H700/H9/i335/i425/i876/ic402/ic502/ic902/KRZR K1/KRZR K1m KRZR K3/KRZR maxx K3/L2/M300/m500/Ming A1200/Ming A1200e MOTO Q9c/MOTO Qmusic9m/MOTOFONE F3/MOTONAV TN20 MotorolaQ/PEBL Red/PEBL U6/RAZR MAXX FERRARI V6/ RAZR MAXX V6/RAZR maxx Ve/RAZR V3/RAZR V3(RED)/RAZR V3 BLK RAZR V3a/RAZR V3c/RAZR V3i/RAZR V3i Chrome White/RAZR V3i DG RAZR V3im/RAZR V3m/RAZR V3r/RAZR V3s/RAZR V3t/RAZR V3x RAZR V3xx/RAZRWIRE Mercury/RAZRWIRE Gray/ RAZRWIRE Pewter/BLACK Iridium/RAZRWIRE Platinum/Gold Iridium red RAZR V3i/red RAZR V3m/RIZR Z3/RIZR Z6tv/ROKR E2/ROKR E6 ROKR S9/ROKR Z6/ROKR Z6m/ROKR Z6w/SLVR (RED)/SLVR i-mode SLVR L6/SLVR L7/SLVR L7c/SLVR L9/SLVR Z10/SLVR L7i/T305/T505 T193/T22xx/The Buzz ic602/V180/V188/V190/V191/V195/V197/V220 V235/V320/V323/V323i/V325/V325i/V360/V361/V365/V2200/V300/V400 V500/V505/V525/V551/V600/V660/V810/VE240/VU204/W175/W177 W180/W220/W230/260g/W315/W370/W372/W375/W376g/W377g W385/W490/W510/W775/Z8/6510/7510/7520/a780/L6/L7/Z3/Z1/Z6/E6/E7	
	BlackBerry	Smartphone	5790/5820/6210/6220/6230/6280/6510/7210/7230/7250/7280/7290 7510/7520/8800/8820/8830/7100g/7100i/7100r/7100t/7100v/7100x 7105t/7130c/7130e/7130g/7130v/8100g/8700c/8700f/8700g/8700r 8700v/8703e/8705g/8707g/8707h/8707v/8808g/Bold 9000/ Curve 8300/Curve 8310/Curve 8310(red)/Curve 8320/Curve 8330 Pearl 8100/Pearl 8110/Pearl 8120/Pearl 8130	
	BlueAnt	Bluetooth	SUPERTOOTH	
	Creative	MP3	ZEN 8GB/Zen Stone/Zen Stone Plus/ZEN X-Fi	
	Garmin	GPS	Edge 205/Edge 305/Edge 605/Edge 705/Forerunner 205/Forerunner 310 Forerunner 305/Forerunner 405	
	HP	PDA	iPAQ 111 Classic Handheld/iPAQ 210/iPAQ 310 Travel Companion iPAQ 510 Voice Messenger/iPAQ 514 Messenger iPAQ rx5915 Travel Companion/iPAQ Travel Companion rx5910 iPAQ Travel Companion rx5915	
	Insignia	MP3	NS-8V24/NS-CNV10/NS-CNV20/NS-DV2G/NS-DV4G/NS-DVB4G Sport NS-DA1G/Sport NS-DA2G	
	iqua	Bluetooth	BHS-302/BHS-303/BHS-603	
	iriver	MP3	Clix GEN2	
	Jabra	Bluetooth	BT2010/BT2020/BT3030/BT530/BT620s	
Jens of Sweden	MP3	MP-400/MP-450/MP-X		

1	Kodak		EasyShare Picture Viewer	
	LG	MP3	HBM-500	
	Mio	GPS	Digi Walker 168/Digi Walker 268/Digi Walker 268+/Digi Walker 269 Digi Walker 336BT/Digi Walker 336g/Digi Walker 336i/Digi Walker 339 Digi Walker 8390/Digi Walker 8870/Digi Walker A201/Digi Walker A701 Digi Walker C230/Digi Walker C320/Digi Walker C510 Digi Walker C510E/Digi Walker C710/Digi Walker P350 Digi Walker P550/Digi Walker C220/Digi Walker 310x Digi Walker C520/Digi Walker720/Digi Walker h610 Knight Rider GPS KITT 300/Moov 200/Moov 210/Moov 300 Moov 310/Moov 330/Moov 370/Moov 500/Moov 510/Moov 560 Moov 580	
	Palm	PDA	Treo 650	
	Rio	MP3	Carbon/ce2100	
	SamSung	MP3	NeXus 25 YP-X5X/NeXus 50 YP-X5Z	
	SanDisk	MP3	Sansa Clip	
	Skype	Wi Fi Phone	Netgear SPH101	
	Sony	MP3	Walkman NW-E405/NW-E407/NW-E507/NW-S205F/NW-S205F	
	SOUTHWING	Bluetooth	SA505	
	TeleNav	GPS	Shothun	
	T-Mobile		Google G1/Sidekick 2008/Sidekick LX/Sidekick Slide	
	TomTom	GPS	GO 520/530/540 LIVE/630 Traffic/720/730/730 Traffic/640 LIVE/920 920T/930/930 Traffic/940/One/ONE 3rd Edition/ONE Europe ONE Regional/ONE XL/ONE XL Europe/ONE XL Regional/ONE XL S	
	Toshiba	MP3	MEU202-SL	
Voice Star	Bluetooth	VS600		
2	Motorola		V8/Q9/V9/Q8/Q9H/V9M	
3	Nokia		6010/6102/N70/N90/N80/82xx/83xx/88xx/6200/6230/6600/6800/6111 6100/6120/N72/N73/7360/3250/6030/6680/6280/5700/N76/N95/6300	
4			1100/1260/1261/2260/3100/3120/3200/3220/3300/3360/3390/3560 /3595/NP-GagcOD/6100/6190/6200/6230/6340/I6560/6620/6682/6820 I7610/8260/8265/3000/3589/5100/6000/6015/3650/5190/3310	
5			8600/7500/8900/8800/7900/6500	
6	SamSung		SA288/SGH-d410/d415/d418/e315/e316/e317/SGH-r225/r225m/n625 v20x/s30x/3500/6100/8500/SGH-p107/p207/x426/x427m/ SGH-s300/s307/s308/SGH-v200/V206/n625/s307/x427m/P107/C207 E317/P207/X497/D307/D357/D508/D608/SCH-n105/q105/SGH-V205	

7			D800/D808/D828/D528/D820/P300/T809/D908/E908/X828/D838/D848 E208/E848/I718/I520/x820/u608/I760/I520/j600/f510e200/e570/i718	
8	SamSung		A516/A737/Access SGH-A827/Ace SPH-i325/Beat SGH-T919 BlackJack II SGH-I617/Blast SGH-T729/Cleo SCH-R800/Epix SGH-i907 Eternity SGH-A867/flipshot SCH-U900/Giorgio Armani Gleam SCH-U700/Glyde SCH-U940/Gravity SGH-T459/SGH-3600 Helio Fin SPH-A513/Hue II SCH-R600/Hue SCH-R500/i200 Instinct SPH-M800/JetSet SCH-R550/Juck SCH-U470/katalyst SGH-T739 Knack SCH-U310/M210/M8800 Pixon/Messenger SCH-R450 Mysto (Helio) SPH-A523/Omnia SCH-i910/Proper SGH-A767 Qbowl SGH-F700MBVVD2/Renown SCH-U810/Rugby A837 Saga SCH-i770/SCH-r200/SCH-R210 Spex/SCH-R300/SCH-R310 Byline SCH-r410/SCH-R430 Myshot/SCH-R610/SCH-U430/SCH-U706 Muse SGH-A117/SGH-A127/SGH-A137/SGH-A226/SGH-A227/SGH-A237 SGH-A516/SGH-A517/SGH-A637/SGH-A736/SGH-A737/SGH-A746 SGH-A777/SGH-B100/SGH-B130/SGH-C180/SGH-C250/SGH-C450 SGH-D880/SGH-E210/SGH-F110 miCoach/SGH-F200/SGH-F210 SGH-F250/SGH-F330/SGH-F400/SGH-F490/SGH-G600/SGH-G800 SGH-i400/SGH-i450/SGH-i550/SGH-i560/SGH-i610/SGH-i616 SGH-i640v/SGH-i780/SGH-J200/SGH-J210/SGH-J400/SGH-J700 SGH-J706/SGH-L170/SGH-L400/SGH-600/SGH-L760/SGH-M110 SGH-M310/SGH-M600/SGH-M610/SGH-P180/SGH-P220/SGH-P260 SGH-P520/SGH-P720/SGH-T109/SGH-T229/SGH-T336/SGH-T339 SGH-T409/SGH-T429/SGH-T439/SGH-T639/SGH-T819/Slash SPH-M310 SLM SGH-A747/Solid SGH-M110/Soul b SGH-U800/Soul SGH-U900 SPH-M300/SPH-M305/SPH-M510/SPH-M520/SPH-530/SPH-Z400 Sawy SCH-U650/Tocco SGH-F480	
9	LG		KG90/KG800/KG90C/VX8500/VX8600/KG70/KG77/ku580/ke850 ke770ke970/KU250/KS10/KU970/KU990/KU380/KU580/KG220/kw820	
10			K750i/z520a/w600i/W800/W550/W900/W500W880/W810/M608c W830/W660I/W580I/W888C/w350/w760//W850/K790c/W700I	
11	SONY Ericsson		T28/k500i/p800/k700/k700i/s700i/T2xx/T3xx/T6xx/P900/R320/T29/T39 R300d/T60x/T61x/T62u/T68/T68i/z200/z500a/z600/T20/T60/T61/T62/T66 T200/T226/T237/T316/T608/T610/T616/R300/R320SC/R380/R520m/A2218 T637/S710a/K500i/k700i/z500a/R300ix/R300Z/T300/T306/Z600/T630/ /A2288/P800/Z200/Z500//T39d	

12	Siemens		C55/sl55/sl56/a56/c56/ct56/m55/m56/a55/m55/sl55/56series/A60/C60 C62/CF62T/MC60/S66/SX1//CF63/A65/S65//S66/C70/C71/C61/CT66/S55	
13	Blackberry		BLACKBERRY 6710/6720/7270/7730/7750/7100t/7510/7520/210/6230 6280/3510/7210/7230/7250/7280/7290/7100g	
14	FOMA		Panasonic P901is/P901i/P901iv/P701i/X800/FOMA NEC N901is/N901ic/N901G/N901il/N901is/N700i/N8/802N FUJITSU F901is/F901ic/F901it/F901ies/F880ies/F700is SHARP SH901is/SH901ic/SH851i/SH700is/SH700i/903SH/703SH/802SH 802SH/902SH/sx313 MITSUBISHI D901is/D901i/D900i	
15	AU		AU/CDMA-1/TG200/CDMA	
16	DOCOMO		DOCOMO/PDC/P101/Digital/2100/S3/GX10/GX20/GX30	
17	Palm		Centro/LifeDriver/Treo 650/Treo 650 Wireless Headset/Treo 680/Treo 700P Treo 700w/Treo 700wx/Treo 750v/Treo 755p/Tungsten E2/Tungsten T5 TX	
18			PalmOne m500/505/515/130/125/i705/Tungsten T/T2/Zire 71	
19	APPLE		Iphone/Iphone 3G/iPod/iPod classic//iPod mini/iPod nano iPod nano video/iPod photo/iPod touch/iPod U2 SE/iPod Video	